

Part # FU1035CABCIMV
 Media HCRSS
 Media volume 25 L.



Quick Set Up Guide

After installing and powering up an Ecosoft FU or FK system, set display language, water hardness, current time, and regeneration options in the Installer menu of control valve.

Use ▲ and ▼ buttons to change setting; NEXT button to save and go to next step; CLOCK to save and exit menu; REGEN to move back one step.

To proceed:

STEP 1. Hold NEXT and ▲ buttons simultaneously for 3 seconds.

STEP 2. Hardness: Set the amount of hardness as calcium carbonate per PPM, dH° or FH°, using ▼ or ▲. Press NEXT to go to Step 4I. Press REGEN to exit Installer Display Settings

STEP 3. Hardness 2: If using a mixing valve, set the amount of effluent hardness using the ▼ or ▲ buttons.

STEP 4. Set Day Override (maximum number of days in service, after which control valve will carry out preventive regeneration). 10 days is recommended. If the water is of poor quality, we recommend regeneration more often (7 days between regenerations)

STEP 5. Set the preferred time of delayed regeneration, hours then minutes (factory set to 2 AM). Any time when water is not used can be set.

STEP 6. Set current time, hours then minutes.

After programming the control valve:

STEP 7. Pour salt into the salt tank of the system to the level of 1/2 to 2/3 of the tank volume

STEP 8. Open the water supply to the softener.

STEP 9. After that, it will start the forced regeneration of the system by pressing the REGEN button for 5 seconds. This is necessary for cleaning the material from impurities and for its stratification



REGEN

